INSTRUCTIONS

E8M ACCESSORY OUTLET KIT

MODEL AP41

WARNING: Remove battery clamp terminating wire 2-01 from the positive post of battery B2 before proceeding with this installation.

1. Allow the upper control panel to tip forward so its mounted components are exposed. See Figure 1.





Figure 1

2. Place the cardboard template so its sides are against the left and center boltheads which secure the control cabinet to the frame. See Figure 2.



DASH COMPARTMENT TO INSTALL OUTLET
Figure 2

- 3. Using a pencil or scriber, draw the outline of the 1-7/16 inch diameter hole on the control cabinet using the template as a guide. If necessary, determine the center of this hole by laying a straight edge across opposite pairs of registration marks on the circumference of the template hole, then drawing a line where it crosses the hole's center.
- 4. Center punch the cross lines of the small 0.166-inch diameter mounting holes for accurate drilling. Make sure the template has not shifted since outlining the larger hole.
- 5. When the template is removed, the outline of the large hole and the centers of the mounting holes should be clearly marked.

CAUTION: Move wires inside control away from area to be drilled.

6. Drill the two mounting holes using a #19 (11/64-inch) drill bit.

Cut the 1-7/16 inch diameter outlet hole into the control cabinet using the outline as a guide.





Figure 3



- 8. Install the accessory outlet from the inside of the control cabinet and secure with #6 hexhead machine screws and lock washers in each of the mounting holes. See Figure 3. The lock washers should be located under the screw heads on the outside of the control cabinet.
- 9. a) For model 26AE8AA tractors only:
 - Attach furnished wire #1-05 from outlet to circuit breaker CB-3 (90-amp) terminal on the same side as the other wire #1. See Figure 4.



CONNECTIONS ON CONTROL PANEL FOR 26AE8AA MODEL

Figure 4

2. Attach furnished wire 30-02 from outlet to circuit breaker CB-2 (50-amp)

terminal on the same side as the other wire #30 also shown in Figure 4.

- b) For all other models-26AE8BA and later
 - Attach wire #30-02 from outlet to CB-2 (50-amp) terminal on the same side as the other wire #30.




Figure 5

- 2. Attach wire #1-05 from outlet to terminal on L contactor on the same side as the other wire #1.
- Recheck all wiring and connections for correctness and tightness before operation.
- 11. Reinstall upper control panel using care to reposition wires as the panel is closed.

PACKING LIST

E8M ACCESSORY OUTLET KIT

AP41AA (155C8171G1)

QTY.	NAME	PART NUMBER
1	OUTLET (WIRES ATTACHED)	244A7436G2
1	TEMPLATE	178B8314P1
2	SCREW, HEX HD 6-32 x 3/8	N68P13006B6
2	LOCKWASHER #6	N405P7C6
1	INSTRUCTIONS	GEH4002