

REPAIR PARTS LIST

NO. L & G 2000

FOR



EGT 80 - ELECTRIC GARDEN TRACTOR

EGT 100 - ELECTRIC GARDEN TRACTOR

EGT 120 - ELECTRIC GARDEN TRACTOR

EGT 150 - ELECTRIC GARDEN TRACTOR

ATTACHMENTS & ACCESSORIES

EFFECTIVE DATE - FEB. 1974



COLDWATER, OHIO 45828, U.S.A.



EGT 80 - EGT 100



EGT 120 - EGT 150

MODEL	LOT NO.	YEAR
EGT 80	LT 1	1973
EGT 80	LT 5	1974
EGT 100	LT 2	1973
EGT 100	LT 6	1974
EGT 120	LT 3	1973
EGT 120	LT 7	1974
EGT 150	LT 4	1973
EGT 150	LT 8	1974

DIRECTIONS FOR ORDERING

DO NOT ORDER REPAIR PARTS FROM ILLUSTRATION ONLY
 ALSO REFER TO THE DESCRIPTION OF THE PART

Always order repairs by number and give the description of the part. Right or left hand parts are determined by standing back of the machine looking in the direction of travel. Also give model, lot and serial number of unit.

When more than one part is used (in each group) it is so indicated in the description of the part.

DESCRIPTION	PAGE	DESCRIPTION	PAGE
Accessory Outlet	32	Main Frame & Attaching Parts EGT 80-100	3-4-5
Brake and Clutch Assembly EGT 80-100	6-7	Main Frame & Attaching Parts EGT 120-150	9-10-11
Brake and Transaxle & Lift EGT 120-150	7-8	36" Mower	24-25
Dump Cart	23	42" Mower	25-26
42" Dozer Blade	34	Manual Rear Lift	30-31
48" Dozer Blade	35	Platform Lift	26
Drive Motor EGT 80-100	36	Power Pack Booster	30-31
Drive Motor EGT 80-120	37	PTO Outlet	33
Electrical System EGT 80 - Standard	11-12	Radio Bracket	32
Electrical System EGT 80 - Extended Range	13-14	Rear Tail Light	33
Electrical System EGT 100	14-15	Rear Electric Lift	38
Electrical System EGT 120	16-17	Sweeper	20-21-22
Electrical System EGT 150	18-19	Sweeper Motor Drive	22
Electric Horn	32	Snow Thrower	27-28
Front Lift Derrick	31	Snow Thrower Lift Assy.	29-30
Front Imple. Mt. Bracket	31	Sleeve Hitch	32
Fuel Gauge	31	Speed Reduction	33
Hitch Adaptor	31	Index	38-39-40
Head Light Kit	33		