

Parts Catalog

John Deere Electric 90 Mower

PC-1279





John Deere Electric 90 Mower 1972 Model-Serial No. (1001-10,000) 1973 Model-Serial No. (10,001-11,704) 1974 Model-Serial No. (11,705-

(Specifications and design subject to change without notice)

AN EXPLANATION OF CHANGE INDICATOR LINE

New and revised information is identified by vertical lines marked in the left-hand margin of revised pages. These lines indicate changes affecting the ordering of parts.

AN EXPLANATION OF SERIAL NUMBER INFORMATION

Serial number information is listed parenthetically to show on which machines each part can be used. These listings are explained by the following examples.

The part can be used on all machines.

(000000-) The part can be used on all machines beginning with the serial number listed.

(-000000) The part can be used on all machines up to and including serial number

(000000-000000) The part can be used on all machines between and including the serial numbers listed.

Where XXXXXX's are listed in place of a serial number it indicates a serial number change was made but the exact serial number had not been established when the catalog went to press.

EXPLANATION OF PARTS LISTED AS "SERVICE ONLY"


Certain parts in this catalog are listed in the description column as "Service Only." These parts serve as a replacement or additional part for service instead of the part originally furnished. The serial numbers shown list the machines on which the "Service Only" part may be used.

ALPHABETICAL INDEX

	Page	1
	Α	Lever, lift
Axle, front		Lever, shift
Axle, rear		Lift stop
	R	Lift Stop
_		M
		Main wiring harness
Belt, traction drive		Main wiring namess
		Motor, mower
Box, battery		Motor, traction
Brake		Mower deck
		0
	C	
Cables, battery		Panel, control
Cable, lift		
Charger, battery		H
Clutch		Resistor
		Reverse idler
Control panel		Rod, lift lever adjusting
Countershaft gears		Rods, shifter
Cover, battery		Rollers, mower
Cover, contactors		
		S
	D	Seat
Deck, mower		Shaft, input
Differential		Sheave, drive and driven
	21,22,23	Shift lever
Drive sheave, traction		Shift lever housing
		Shifter forks
		Shifter rods
	F	
Forks, shifter	F	Shroud Solenoids
Forks, shifter	F	Solenoids
Frame		Sclenoids Steering gear Steering wheel
Frame		Solenoids Steering gear Steering wheel Switch, main
Frame		Sclenoids Steering gear Steering wheel
Frame	3 21,22,23	Solenoids Steering gear Steering wheel Switch, main Switch, mower
Frame		Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start
Frame Fuse Gear case, transaxle Gears, countershaft	G 13 15	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start
Frame	3 21,22,23 G 13 15 14	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start Tire, front
Frame	G 13 15	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start Tire, front Tire, rear
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals	3 21,22,23 G 13 15 14 16 H	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main	3 21,22,23 G 13 15 14 16 H 21,22,23	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main	3 21,22,23 G 13 15 14 16 H 21,22,23	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower moto Hold-down, battery	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever	3 21,22,23 G 13 15 14 16 H 21,22,23 78 25,26 18	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle	3 21,22,23 G 13 15 14 16 H 21,22,23 78 25,26 18 9	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18 9 13 12	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, rear
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle	3 21,22,23 G 13 15 14 16 H 21,22,23 78 25,26 18 9	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, rear Wheel, steering
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle Hub, rear wheel	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18 9 13 12 H	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, rear Wheel, steering
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle Hub, rear wheel	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18 9 13 12 1	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, steering Wiring harness, main
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle Hub, rear wheel	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18 9 13 12 H	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, steering Wiring harness, main
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower motor Hold-down, battery Housing, shift lever Housing, transaxle Hub, rear wheel	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18 9 13 12 1	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, steering Wiring harness, main
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower moto Hold-down, battery Housing, shift lever Housing, transaxle Hub, rear wheel Idler, reverse Input, shaft	3 21,22,23 G 13 15 16 H 21,22,23 TS 25,26 18 9 13 12 I	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, steering Wiring harness, main Wiring harness, mower motors
Frame Fuse Gear case, transaxle Gears, countershaft Gears, drive Guard, chute, with decals Harness, wiring, main Harness, wiring, mower moto Hold-down, battery Housing, shift lever Housing, transaxle Hub, rear wheel Idler, reverse Input, shaft	3 21,22,23 G 13 15 14 16 H 21,22,23 (S 25,26 18 9 13 12 1	Solenoids Steering gear Steering wheel Switch, main Switch, mower Switch, safety-start T Tire, front Tire, rear Traction drive belt Traction motor Transaxle gear case assembly W Wheel, front Wheel, gauge, mower Wheel, steering Wiring harness, main Wiring harness, mower motors

								Page
	L							100
Lever, lift					 	 		. 10
Lever, shift					 	 		9
Lift stop					 	 		. 10
	M							
Main wiring harness					 	 	. 21,	22,23
Motor, mower					 	 		25,26
Motor, traction								
Mower deck								
	P							
Panel, control					 	 		4
	R							
Resistor					 	 	21,	22,23
Reverse idler					 	 		. 14
Rod, lift lever adjusting					 	 		. 10
Rods, shifter					 	 		. 15
Rollers, mower					 	 		. 16
	S							
Seat					 	 		4
Shaft, input					 	 		. 13
Sheave, drive and driven					 	 	5	,6,24
Shift lever					 	 		9
Shift lever housing		4			 	 		9
Shifter forks					 	 		. 15
Shifter rods	1				 	 		. 15
Shroud					 	 		4
Solenoids						 	21,	22,23
Steering gear					 	 		11
Steering wheel					 	 		11
Switch, main						 	21,	22,23
Switch, mower						 	21,	22,23
Switch, safety-start					 	 	21,	22,23
	T							
Tire, front					 	 		11
Tire, rear					 	 		12
Traction drive belt					 	 		5,6
Traction motor					 	 		24
Transaxle gear case assembly					 	 		13
semestra altrafament graph								
	W							
Wheel, front					 	 		11
Wheel, gauge, mower					 	 		16
Wheel, rear					 	 		12
Wheel, steering		00	au	00	 	 		11
Wiring harness, main					 	 	21,	22,23
Wiring harness, mower motors					 	 		25,26

FRAME, BATTERY BOX, AND CONSOLE



	Key	Part No.	Serial No.	Description	
	1	AM 33914	(-10000	Box, battery	
١		AM 34658	(10001 - 11704)	Box, battery	
١		AM 35274	(11705 -	Box, battery	
•	2	3H 1268	1 -	Bolt, cge., 5/16" x 3/4" (4 used)	
	3	12H 303	1 -	Washer, lock, 5/16" (17 used)	
	4	24H 1136	1 -	Washer, 11/32" x 11/16" x .060" (8 used)	
	5	14H 785	1 -	Nut, 5/16" (19 used)	
	6	37H 126	1 -	Screw, self-tapping, No. 8 x 3/8" (3 used)	
	7	M 46433	1 -	Cap, console	
	8	M 45262	1 -	Bushing, plastic	
ľ	9	M 46440	1 - 11704	Latch, lever	
		M 48417	(11705 -	Latch, lever	
	10	21H 1302	1 -	Screw, mach., 1/4" x 5/8" (2 used)	
		12H 302	- the day	Washer, lock, 1/4"	
	11	AM 33978	1 -	Console	
	12	M 46519	- 10000	Label, instruction	
		M 47426	(10001 -	Label, instruction	
	13	AM 33750	1000.	Kit, foot-tread (includes R.H. and L.H. treads)	
	14	M 46385	1 -	Support, axle, rear	
	15	14H 812	1 -	Nut, 3/8" (6 used)	
	16	12H 304	} -	Washer, lock, 3/8" (6 used)	
	17	19H 1936	1	Screw, cap, 3/8" (6 used)	
	18	M 46437	-	Plate, hitch	
	19	19H 1731	- }	Screw, cap, 3/8" x 1" (2 used)	
	20	3H 1539		Bolt, cge., 5/16" x 5/8" (2 used)	
	21	19H 1813	- 50000 85	Screw, cap, 5/16" x 5/8" (5 used)	
	22	M 46442	} -	Rod, support, shroud	
	23	11H 206	} -) Pin, cotter, 3/32" x 3/4" (2 used)	
	24	H 23197	- 1500	Grommet (2 used)	
		M 44391	1501 -	Edging, vinyl (10 ft. long) (cut as required)	
	25	M 46796	1501 -	Grommet (2 used) (sub. for M46492)	
	26	M 44391		Edging, vinyl (10 ft. long) (cut as required)	
1	27	M 47447	(10001 - 11704	Decal, electric system	
ı		M 48727	(11705 -	Decal, electric system	
ı	28	19H 1905	(11705 -	Screw, cap, 5/16" x 1" (2 used)	
ı	29	24H 1224	(11705 -	Washer, 11/32" x 1" x .060" (4 used)	
1	30	M 41394	(11705 -	Washer, fiber, 11/32" x 1" x .060" (4 used)	
1	31	M 41393	(11705 -	Washer, fiber, 11/32" x 41/64" x .060" (2 used)	
1	32	M 48418	(11705 -	Decal, cutting height	
1	02	W 40410	1	Frame (dealer contact branch service department wh	en required)
1		AM 35067	1 .	Kit, French and English decal	
	**	00001	1	, and the second	