



## DESCRIPTION

You will find many work-saving uses for your lawnsweeper. Use it in early spring to give your lawn a good healthful scrubbing. Use it throughout the spring and summer both before and after mowing. Sweeping before mowing stands up grass for a clean, even cut - and protects your mower from sticks, stones, or nuts which might damage the blades of your mower. After mowing, your lawnsweeper will whisk away unsightly grass clippings - leaving your lawn velvety smooth.

Your new Trailer-Sweeper is precision manufactured by experienced craftsmen, using the finest in tools and materials. Although it is ruggedly constructed do not subject it to misuse. CAUTION: DO NOT PULL YOUR UNIT TOO CLOSE TO FIRE - the brushes and hamper will burn. Be sure to wipe off your unit after each use. Store in a dry place out of direct sunlight. Don't permit the sweeper to stand in the hot sun unless it is in actual use.

\* REQUIRES KS33 ELECTRIC POWER CONVERSION KIT

## **OPERATION**

1. BRUSH ADJUSTMENT: Your new trailer-sweeper is equipped with a handy, "from the tractor seat," brush adjustment. To raise, push adjustment tube back and down until desired sweeping height is attained. To lower, push adjustment tube back and pull up to desired sweeping height. See Fig. 4. For best results, brush should merely flick tops of grass blades. Brushes should be raised when transporting to and from sweep area.

**CONVERTIBLE TO ELECTRIC SWEEPER\*** 

- 2. SWEEPING SPEED: For best results, the tractor should travel at a speed of 3 to 5 M.P.H.
- 3. DUMPING: Exclusive Flip-O-Matic rear dump action with Lift-Out Hamper feature. To dump merely pull on Nylon Rope until Hamper turns over dumping debris. Return hamper slowly to its original position by keeping pressure on rope.

IN THE FALL: Sweep REGULARLY when the leaves are dropping . . . don't wait until they're all down . . . you'll get better sweeping action if your lawn is cut

## Made for

New Idea Farm Equipment 420 S. Front St. Coldwater, Ohio 45828 By Lambert Corporation

