

INSTALLATION AND OPERATING INSTRUCTIONS FOR SNOW THROWER.

BUNDLE NO. 100-0003 FOR EGT 80, EGT 100, EGT 120

AND EGT 150 ELECTRIC GARDEN TRACTORS.

NOTE:

- . All illustrations in this manual are shown with the EGT 100 and 120 Electric Garden Tractor. All adjustments and set up instructions are the same on all tractors except where noted.
- . The snow thrower will take a 38" cut. By adding diverter wings, Bundle No. 120-0016, a 42" cut is available.
- . The P. T. O. outlet, Bundle No. 080-0009, must be installed on the EGT 80 and EGT 100 model tractors.
- . The extended range kit, Bundle No. 080-0007, must be installed on the EGT 80 tractor.
- . A speed reduction kit, Bundle No. 080-0008, is available for the EGT 80 and EGT 100 tractors.
- . To attach the snow thrower, remove any other mounted tractor attachments, such as rotary mower, snow/dozer blade, etc. The Front Implement Mounting Bracket must be installed before proceeding. Bundle No. 080-0005 must be installed on the EGT 80 and EGT 100 tractors. Bundle No. 120-0008 must be installed on the EGT 120 and EGT 150 tractors. See the separate instruction sheet for installation of this bracket.
- . Terms left and right as used in this manual refer to the left and right side of the equipment when facing forward from the rear of the tractor.
- . The snow thrower and all necessary parts and hardware are packed in one container. Unpack the container carefully to insure that all sub-assemblies and parts are removed.

TABLE OF CONTENTS

Set Up	2 thru 6
Installation of Lift Strap and Helper Springs	
EGT 150 Tractor only	6
Safety Practices	7
Operation	7 thru 12
Service and Maintenance	15
Lubrication	15
Adjustments	9 thru 11
Cleaning	15
Storage	15

