



Electrak[®]


Tractor

INSTRUCTIONS

GEH-3959

INVERTER

Model AP60



CONTENTS

	<u>Page</u>
Safety First.....	2
Description.....	3
Application.....	3
Operation.....	3
Installation.....	3
Care and Maintenance.....	4
Specifications.....	4
Warranty.....	4

SAFETY FIRST

1. Each operator should fully understand the entire contents of this manual before use.
2. The inverter must only be plugged into the Elec-Trak tractor accessory receptacle (36-volts d-c). Use with any other power source may cause the unit to malfunction and could cause a hazardous condition.
3. Never use the inverter if it is wet or in wet areas, to prevent any possibility of electric shock.
4. Never attempt to operate the inverter while the charger is plugged in, to avoid possible shock hazard and damage to equipment.
5. To prevent accidental tractor movement while using the inverter, turn the key switch off and set the parking brake.
6. The inverter should be used with the same caution as any other source of 117-volt a-c power.

These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the General Electric Company.

